## BEFORE USE

- Remove all packaging from the kettle and power base.
- Remove any labels from the outer stainless steel surfaces.
- Remove the filter (fig. 1) and wash with water (fig. 2). Refer to page 8. "Removing the water filter"
- Fill the kettle with water, plug power cord into outlet and turn the unit "ON" (for details see "Switching On").
- The boiled water should be discarded and the kettle rinsed out with cold water. This procedure should be carried out three times, to remove any manufacturing dust, etc.
- After the kettle has been rinsed out, replace the filter (fig. 3).






## IN USE

### Power base with 360° access

With the specially designed power base and central connector, you can now set the kettle on the base at any angle, from any position.

- Release cord from storage base and adjust length by winding around the base to give the correct cord length to reach the outlet to be used (fig. 4).
- Do not leave loose cord hanging over the edge of work surfaces.




### Filling

- Remove the kettle from the base unit before filling.
- Open lid and fill kettle to desired level.
  In some models, a handy external water level indicator (I) enables you to see the quantity of water in the kettle.
  **Do not fill with less than 0,25 liters(10-Ounces) of water** to prevent the kettle running dry while operating; misuse of this kind will shorten the life of the element.
  **Do not fill with more than 1,7 liters (58-Ounces) of water** (up to the MAX indication located inside the kettle) (fig. 5). **If the kettle is overfilled, there is a risk that boiling water may be ejected causing burns.**
  A handy water level indicator enables you to see the quantity of water in the kettle.



### Switching on




- Plug the power base into the outlet.
- Place kettle on power base.
- Press the ON/OFF switch down (fig. 6) to switch the kettle on.
- The indicator light will switch on.
- The kettle will automatically switch off once the water is boiled (the ON/OFF switch will click upwards and the lights will go out).
- To turn the kettle off before the water boils, you may move the ON/OFF switch up to the OFF position, or simply lift the kettle from its base - it will switch off and the switch will return to the OFF position automatically.

### Pouring

- Remove the kettle from the power base and carefully pour out the water. Do not tilt kettle suddenly or pour out at too sharp an angle.
- When you lift the kettle from the base, you may see moisture on the top surface of the base. This is condensation from the steam that causes the kettle to turn off automatically after boiling. Steam is allowed to escape via vents in the underside of the kettle. **Condensation on the base is perfectly normal, and should not be a cause for alarm.**

## SAFETY DEVICES

### 1) Automatic ON/OFF switch

Your kettle is fitted with an ON/OFF switch which automatically switches off once the water has boiled. If the kettle has just boiled, wait a minute or so before re-boiling the kettle. **Do not attempt to hold the ON/OFF switch in the on position or adjust the switch mechanism.**

### 2) Safety cut-off

If the kettle is switched ON with too little or no water, it is protected against damage by a safety cut-out which will switch off the power.
If this cut-off operates, disconnect the kettle from the outlet and **leave to cool down** before refilling with cold water (otherwise the element could be damaged).

**3)** If kettle is lifted from base while operating (ON), it will automatically switch off.

## CARE AND MAINTENANCE

### Cleaning the kettle

- Allow the kettle to cool down fully and disconnect the appliance from the outlet before cleaning.
- Do not immerse the kettle or base in water.
- Use a soft dampened cloth to wipe the outside of the kettle and dry with a soft, dry cloth.
- DO NOT use metal polish or harsh scouring agents.
- Ensure that all connectors and sockets are kept dry.

## Scale

Scale is mainly calcium carbonate (chalk), a harmless, naturally occurring mineral found in most water supplies. “Hard” water contains more of this mineral than “soft” water.
When the water is heated, the minerals in the water solidify, making the water appear cloudy. These minerals form a thin film on the walls, element and on the surface of the water. The water may look like it has white colored pieces of plastic floating on the surface.
On traditional kettle elements, scale forms a hard white “crust” which adversely affects performance and reduces the life of the element.
As soon as you notice a film forming on the water, or, when cleaning the filter, if you notice a film on the walls or the element, simply rinse the kettle and wipe it out.

## Water filter

Your kettle is fitted with a water filter to prevent loose particles of scale being poured into your beverage. This filter is both removable and washable.
The frequency with which you will need to clean any scale deposits from your filter will depend on the hardness of water in your area and how often you use the kettle.
You should remove and clean the water filter when you notice any deposits being left on the filter or if the pouring efficiency is impaired.

## Removing the water filter

- Allow the kettle to cool down completely.
- Disconnect the appliance from the outlet.
- Make sure that your hands are clean and free from soap, cream or anything which might taint the water.
- Empty the kettle and remove the water filter as shown in fig. 1.
- Rinse under a tap while cleaning with a soft brush (fig. 2).
- Replace the filter (fig. 3).

## To clean a water filter

It is vital to clean and descale regularly in order to maintain good working order
We recommend using white vinegar as follows:

- Pour into kettle about 50 gr. or 2 oz. of white vinegar and then fill with water up to the max level indicated and then boil. Allow the contents to cool, and then rinse thoroughly.
- Do not use a more concentrated solution. If the filter requires descaling, remove the filter and place into the white vinegar solution in the kettle.
- Ensure that the electrical connections are completely dry before using the kettle.

# LIMITED WARRANTY

**What does the warranty cover?**
We warrant each appliance to be free from defects in material and workmanship. Our obligation under this warranty is limited to repair at our factory or authorized service center of any defective parts or part thereof, other than parts damaged in transit. In the event of a products replacement or return, the unit must be returned transportation prepaid. The repaired or new model will be returned at the company expense.
This warranty shall apply only if the appliance is used in accordance with the factory directions, which accompany it, and on an Alternating current ( AC ) circuit.

**How long does the coverage last?**
This warranty runs for one year ( 1 ) from the purchase date found on your receipt and applies only to the original purchaser for use.

**What is not covered by the warranty?**
The warranty does not cover defects or damage of the appliance, which result from repairs or alterations to the appliance outside our factory or authorized service centers, nor shall it apply to any appliance, which has been subject to abuse, misuse, negligence or accidents. Also, consequential and incidental damage resulting from the use of this product or arising out of any breach of contract or breach of this warranty are not recoverable under this warranty. Some states do not allow the exclusion or limitation of incidental or consequential damage, so the above limitation may not apply to you.

**How do you get service?**
If repairs become necessary please contact our toll free hotline at **1-800-322-3848** or log onto our website at **www.delonghi.com.**
For all accessories, spare parts or replacement parts, please contact our parts division at **1-800-865-6330.**
The above warranty is in lieu of all other express warranties and representations. All implied warranties are limited to the applicable warranty period set forth above. This limitation does not apply if you enter into an extended warranty with De'Longhi. Some states do not allow limitations on how long an implied warranty lasts, so the above exclusions may not apply to you. De'Longhi does not authorize any other person or company to assume for it any liability in connection with the sale or use of its appliance.

**How does state law apply?**
This warranty gives you specific legal rights, and you may also have other rights, which vary from state to state.